



DATA EAST PINBALL, INC.

SERVICE BULLETIN

DATE: April 26, 1988

GAME: Secret Service

#005

SUBJECT: Up Post Adjustments

Symptom: The up post will not latch down. The coil and switch check good in self test.

Problem: Refer to attached picture and follow along with this text.

The hole in the guide bracket (item 17) for the coil plunger is 1/16" off. Therefore, the guide shaft screw (item 23) is 1/16" too far away from the dual action shaft release (item 25). The end result is the post won't latch down.

- Solution:**
1. Remove the E ring, two flat washers, stud spring, and the dual action shaft release (items 20, 21, 22, and 25).
 2. Remove the #0-32 elastic stop nut from the guide shaft screw (item 18).
 3. Remove the guide shaft screw.
 4. Shim the guide shaft screw further into the dual action shaft release by placing two 1/32" flat washers onto the guide shaft screw.
 5. Re-assemble the up post assembly.
 6. Test unit for positive latching.

Pete Gustafson
Field Service Manager
Data East Pinball, Inc.

Page 1 of 1